



GSD TD VALVE PARTS

TD VALVE PARTS



TD VALVE PARTS LIST

Above Identifier	Description	4" Part#	5" Part#	6" Part#
1	Vaulve Frame	TD9206115	TD9206115	TD9206116
2	Offset Tube	TD9206124	TD9206125	TD9206126
3	Output Tube	TD9206134	TD9206135	TD9206136
4	Output Tube Gasket	TD9206144	TD9206145	TD9206146
5	Output Tube Spacer	TD9206154	TD9206155	TD9206156
6	Bronze Busing	TD9206165	TD9206165	TD9206165
7	Springs	TD9206175	TD9206175	TD9206175
8	Adjusting Nut	TD9206185	TD9206185	TD9206185
9	Input Tube	TD9206194	TD9206195	TD9206196
10	Wing Nut Coupler	TD92061104	TD92061105	TD92061106
11	Handle Grip	TD92061115	TD92061115	TD92061115
12	UHMW Slide	TD92061125	TD92061125	TD92061126
13	Slide Frame	TD92061135	TD92061135	TD92061136
14	Tension Handle Left	TD92061145	TD92061145	TD92061145
15	Tension Handle Right	TD92061155	TD92061155	TD92061155
16	Output Tube Retainer	TD92061164	TD92061165	TD92061166

Otwell Sales Warehouse
 7702 E St Rd 356
 Otwell, IN 47564
 Phone: (855) 354-2496
 Fax: (812) 354-6517
 otwell@grainsystemsdist.com

Milford Sales Warehouse
 601 N Old SR 15
 Milford, IN 46542
 Phone: (574) 831-4120
 Fax: (574) 831-5129
 milford@grainsystemsdist.com

Rock Falls Sales Warehouse
 1104 Industrial Park Road
 Rock Falls, IL 61071
 Phone: (815) 625-2838
 Fax: (815) 625-2995
 rockfalls@grainsystemsdist.com