




UTILITY AUGER

PARTS MANUAL

TABLE OF CONTENTS

DESCRIPTION	PAGE
UT-4 UTILITY AUGER	4
UT-6 UTILITY AUGER	6
UT-8 UTILITY AUGER	10
UT-10 UTILITY AUGER	14
UT-13 UTILITY AUGER	18


UT-4 UTILITY AUGER



UT-4 UTILITY AUGER

ITEM	PART NO.	DESCRIPTION
1	10-18213	UB411 TUBE ONLY
1A	10-18353	UB411 TUBE BUNDLE
2	10-18214	UB411 FLIGHT SECTION
3	10-18215	UX405 TUBE ONLY
3	10-18216	UX410 TUBE ONLY
4	10-18217	UX405 FLIGHT SECTION
4	10-18218	UX410 FLIGHT SECTION
5	10-18219	UT4 INTAKE
6	10-18220	UT4 TUBE CONNECTOR CLAMP
7	10-18221	UT4 MOTOR MOUNT
8	10-17073	SHIELD, UT4 8" PULLEY
9	10-18223	UT4 FEED CONTROL
10	10-18224	UT4 FEED CONTROL CLAMP
11	10-18226	UT4 INTAKE CLAMP
12	10-18225	NARROW HALF CLAMP
13	10-18227	UT4 SWIVEL CLAMP
14	10-18228	UT4 SWIVEL BRACKET
15	10-18229	UT4 BOX CLAMP
16	10-17075	PULLEY, 8" X 7/8" SNGL A
17	10-17074	BELT, A33
18	10-18232	UT4 WOOD BEARING
19	10-18233	UT4 FLIGHT CONNECTOR
20	10-19838	ADJUST SCREW, T-BOLT
21	10-19225	SETSCREW, 3/8" UNC X 3/8" REGULAR
22	10-19274	SELF TAPPING SCREW 9900132
23	10-19538	BOLT, 5/16X3/4 PLTD 9900797
24	10-19595	WHIZNUT 5/16" 9900129
25	10-19980	LOCKNUT, 5/16" PLTD
26	10-19224	1/4" X 1" WOODRUFF KEY (4503192)
27	10-17121	UT4 HOPPER ASSEMBLY
28	10-17122	UT4 STUB SHAFT
29	10-17314	7/8" RIM WASHER
30	10-18091	5/16" X 1" NC BOLT GR 2 PLTD


UT-6 UTILITY AUGER



UT-6 UTILITY AUGER

ITEM	PART NO.	DESCRIPTION
1	10-19820	TUBE ONLY, UB616
1A	10-19823	UB616 TUBE BUNDLE
2	10-19826	FLIGHT SECTION, UB616
3	10-19829	INTAKE, UT6
4	10-19832	FEED CONTROL, UT6
5	10-19835	CLAMP, UT6 FEED CONTROL
6	10-19022	W60 HALF CLAMP
7	10-19838	ADJUST SCREW, T-BOLT
8	10-28426	6/7/8 FRONT MOUNT PLATE
9	10-27461	6/7/8 REAR MOUNT PLATE
10	10-27462	6/7/8 MOTOR MOUNT
11	10-27463	6/7/8 HINGE ROD
12	10-27464	6/7/8 SHIELD STRAP
13	10-19321	BEARING W 2 2-HOLE FLANGES
13A	10-18817	1 FLANGE BEARING ONLY 4503130
14	10-19613	PULLEY, 12.7 X 1 DBL B W19613
15	10-19843	BELT, B48
16	10-19845	SHIELD, UT PULLEY
17	10-19846	TUBE ONLY, UX605
17	10-19849	TUBE ONLY, UX610
17	10-19852	TUBE ONLY, UX615
18	10-19855	FLIGHT SECTION, UX605
18	10-19858	FLIGHT SECTION, UX610
18	10-19861	FLIGHT SECTION, UX615
19	10-27249	WC1335 ADJUST BOLT
20	10-19589	BOLT 1/2" X 1-1/2" 9900536
22	10-19542	BOLT, 7/16" X 1" PLTD 4500068
23	10-18955	BOLT 3/8" X 1" 9900699
25	10-19538	BOLT, 5/16X3/4 PLTD 9900797
26	10-19537	1/4X1/2 BOLT WSHR HEAD9900170
27	10-19864	NUT, 5/8"HEX
28	10-19599	LOCKNUT 1/2" 9900538
29	10-19598	LOCKNUT 7/16" 9900643
30	10-17402	LOCKNUT 3/8" 0601007
32	10-19595	WHIZNUT 5/16" 9900129
33	10-19594	WHIZNUT 1/4" 9900130
34	10-17401	WASHER 1/2" FLAT 9900565
35	10-19271	COTTER PIN 1/8 X 1-1/2 C.ZINC PLTD
36A	10-19224	1/4" X 1" WOODRUFF KEY (4503192)
37	10-19274	SELF TAPPING SCREW 9900132
38	10-19868	BRACKET, UT6 BUSHING
39	10-19871	SHAFT, UT6/7 STUB
40	10-19873	UT6 HOPPER ONLY
41	10-18690	1 WOOD BEARING
41A	10-18694	FLANGE
42	10-19876	TRUSS STRUT, UT6
43	10-19879	BRACE, UT TRUSS BRACKET
44	10-19333	5/16" CABLE CLAMP (YELLOW ZINC)
45	10-19880	CLAMP, UT6 TRUSS ANCHOR
46	10-19332	REG TRUSS ATTACH ANGLE BRACKET


UT-6 UTILITY AUGER



UT-6 UTILITY AUGER

ITEM	PART NO.	DESCRIPTION
47	10-19331	EYE BOLT/NUT 1/2" X5" 4503071
48	10-19883	TRUSS CABLE, 5/16"X30'
48	10-19884	TRUSS CABLE, 5/16"X40'
49	10-19149	1" BUSHING
50	10-19222	GREASE FTG ZERK 1/4-28 SAE CZ PLTD
58	10-29714	UT6 BOLT ON HOPPER LID
59	10-28449	LOCKNUT 1/4" 9900562
60	9900683	FLAT WASHER, 1/4" PLTD
61	9900800	1/4" X 3/4" NC BOLT GR 5 PLTD


UT-8 UTILITY AUGER



UT-8 UTILITY AUGER

ITEM	PART NO.	DESCRIPTION
1	10-19822	TUBE ONLY, UB816
1A	10-19825	UB816 TUBE BUNDLE
2	10-19828	FLIGHT SECTION, UB816
3	10-19831	INTAKE, UT8
4	10-19834	FEED CONTROL, UT8
5	10-19837	CLAMP, UT8 FEED CONTROL
6	10-19460	CLAMP, W80 HALF
7	10-19838	ADJUST SCREW, T-BOLT
8	10-28426	6/7/8 FRONT MOUNT PLATE
9	10-27461	6/7/8 REAR MOUNT PLATE
10	10-27462	6/7/8 MOTOR MOUNT
11	10-27463	6/7/8 HINGE ROD
12	10-27464	6/7/8 SHIELD STRAP
13	10-19322	1-1/4 2 HOLE FLANGE BEARING
13A	10-18853	EFH206-20 BEARING
14	10-19613	PULLEY, 12.7 X 1 DBL B W19613
14	10-28473	PULLEY,12.35 X 1 TRPL B 1900018
15	10-19844	BELT, B51
16	10-19845	SHIELD, UT PULLEY
17	10-19848	TUBE ONLY, UX805
17	10-19851	TUBE ONLY, UX810
17	10-19854	TUBE ONLY, UX815
18	10-19857	FLIGHT SECTION, UX805
18	10-19860	FLIGHT SECTION, UX810
18	10-19863	FLIGHT SECTION, UX815
19	10-27249	WC1335 ADJUST BOLT
20	10-19589	BOLT 1/2" X 1-1/2" 9900536
21	10-19545	7/16" X 2-1/4" NC BOLT GR 8 PLTD
22	10-19542	BOLT, 7/16" X 1" PLTD 4500068
23	10-18955	BOLT 3/8" X 1" 9900699
24	10-19540	BOLT, 3/8 X 3/4" PLT 9900530
26	10-19537	1/4X1/2 BOLT WSHR HEAD9900170
27	10-19864	NUT, 5/8"HEX
28	10-19599	LOCKNUT 1/2" 9900538
29	10-19598	LOCKNUT 7/16" 9900643
30	10-17402	LOCKNUT 3/8" 0601007
31	10-19596	WHIZNUT 3/8" 9900788
33	10-19594	WHIZNUT 1/4" 9900130
34	10-17401	WASHER 1/2" FLAT 9900565
35	10-19271	COTTER PIN 1/8 X 1-1/2 C.ZINC PLTD
36	10-19606	KEY, 1/4" X 1-1/2" SQ 700615
37	10-19274	SELF TAPPING SCREW 9900132
38	10-19870	BRACKET, UT8 BUSHING
39	10-19872	SHAFT, UT8 STUB
40	10-19875	UT8 HOPPER ONLY
41	10-18690	1 WOOD BEARING
41A	10-18694	FLANGE
42	10-19878	TRUSS STRUT, UT8
43	10-19879	BRACE, UT TRUSS BRACKET
44	10-19333	5/16" CABLE CLAMP (YELLOW ZINC)


12



UT-8 UTILITY AUGER

ITEM	PART NO.	DESCRIPTION
45	10-19882	CLAMP, UT8 TRUSS ANCHOR
46	10-19332	REG TRUSS ATTACH ANGLE BRACKET
47	10-19331	EYE BOLT/NUT 1/2" X5" 4503071
48	10-19883	TRUSS CABLE, 5/16"X30'
48	10-19884	TRUSS CABLE, 5/16"X40'
49	10-19149	1" BUSHING
50	10-19222	GREASE FTG ZERK 1/4-28 SAE CZ PLTD
58	10-29716	UT8 BOLT ON HOPPER LID
59	10-28449	LOCKNUT 1/4" 9900562
60	9900683	FLAT WASHER, 1/4" PLTD
61	9900800	1/4" X 3/4" NC BOLT GR 5 PLTD
62	10-18695	1-1/4" FLANGE, 2-HOLE
63	10-19538	BOLT,5/16X3/4 PLTD 9900797
64	10-19595	WHIZNUT 5/16" 9900129
65	10-12623	COLLAR, LOCK 1-1/4" ECL

14




UT-10 UTILITY AUGER

ITEM	PART NO.	DESCRIPTION
1	10-18235	UB1016 TUBE ONLY
1A	10-18355	UB1016 TUBE BUNDLE
2	10-18236	UB1016 FLIGHT SECTION
3	10-18254	UX1005 TUBE ONLY
3	10-18256	UX1010 TUBE ONLY
3	10-18258	UX1015 TUBE ONLY
4	10-18255	UX1005 FLIGHT SECTION
4	10-18257	UX1010 FLIGHT SECTION
4	10-18259	UX1015 FLIGHT SECTION
5	10-18237	UT10 INTAKE
6	10-18238	UT10 FEED CONTROL
7	10-28336	FRONT MOUNT PLATE, U-TROUGH
8	10-27466	10/13 REAR MOUNT PLATE
9	10-27467	10/13 MOTOR MOUNT
10	10-27468	10/13 HINGE ROD
11	10-27469	10/13 SHIELD SPACER
12	10-19845	SHIELD, UT PULLEY
13	10-19930	PULLEY SHIELD EXTENSION
14	10-18245	UT10/13 LOWER SHIELD MOUNT
15	10-19801	CLAMP, W100 HALF
16	10-18246	UT10 FEED CONTROL CLAMP
17	10-19950	15" X 1-1/4" DOUBLE B GROOVE PULLEY
17	10-19933	15" X 1-1/4" TRIPLE B GROOVE PULLEY
18	10-19934	B62 BELT
19	10-19567	BEARING, 1-1/4" PILLOW 4500067
19A	10-18852	1-1/4" BEARING, LESS FLANGE
20	10-18247	UT10 STUB SHAFT
21	10-18248	UT10 BUSHING BRACKET
22	10-18249	UT10 HOPPER
23	10-18691	1-1/4" WOOD BEARING
23A	10-18695	1-1/4" FLANGE, 2-HOLE
24	10-18250	UT10 TRUSS STRUT
25	10-18251	UT10 STRUT BRACE
26	10-18252	UT10 TRUSS ANCHOR CLAMP
27	10-19332	REG TRUSS ATTACH ANGLE BRACKET
28	10-19883	TRUSS CABLE, 5/16"X30'
28	10-19884	TRUSS CABLE, 5/16"X40'
29	10-17854	1/4" X 2-1/2" SQUARE KEY
30	10-19274	SELF TAPPING SCREW 9900132
31	10-19331	EYE BOLT/NUT 1/2" X5" 4503071
32	10-19333	5/16" CABLE CLAMP (YELLOW ZINC)
33	10-19838	ADJUST SCREW, T-BOLT
34	10-19271	COTTER PIN 1/8 X 1-1/2 C.ZINC PLTD
35	10-19776	BUSHING, 1-1/4"
36	10-19222	GREASE FTG ZERK 1/4-28 SAE CZ PLTD
37	10-27249	WC1335 ADJUST BOLT
38	10-19798	1/2" X 2-3/4" NC BOLT GR 8 PLTD
39	10-19589	BOLT 1/2" X 1-1/2" 9900536
40	10-19542	BOLT, 7/16" X 1" PLTD 4500068
41	10-18955	BOLT 3/8" X 1" 9900699

UT-10 UTILITY AUGER

ITEM	PART NO.	DESCRIPTION
42	10-19537	1/4X1/2 BOLT WSHR HEAD9900170
43	10-19864	NUT, 5/8"HEX
44	10-19599	LOCKNUT 1/2" 9900538
45	10-19598	LOCKNUT 7/16" 9900643
46	10-17402	LOCKNUT 3/8" 0601007
47	10-19594	WHIZNUT 1/4" 9900130
48	10-17401	WASHER 1/2" FLAT 9900565
58	10-19596	WHIZNUT 3/8" 9900788
59	10-29717	UT10 BOLT ON HOPPER LID
60	10-28449	LOCKNUT 1/4" 9900562
61	9900683	FLAT WASHER, 1/4" PLTD
62	9900800	1/4" X 3/4" NC BOLT GR 5 PLTD

UT-13 UTILITY AUGER



ILL929

UT-13 UTILITY AUGER

ITEM	PART NO.	DESCRIPTION
1	10-17493	UB1321 TUBE ONLY
1A	10-17395	UB1321 TUBE BUNDLE
2	10-17494	UB1321 FLIGHT SECTION
3	10-17499	UX1305 TUBE ONLY
3	10-17500	UX1310 TUBE ONLY
3	10-17501	UX1320 TUBE ONLY
4	10-17491	UX1305 FLIGHT SECTION
4	10-17492	UX1310 FLIGHT SECTION
4	10-18984	MK130 MIDDLE FLIGHT SECTION
5	10-17495	UT13 INTAKE
6	10-17484	UT13 LOWER FLIGHT STUB
7	10-28336	FRONT MOUNT PLATE, U-TROUGH
8	10-27466	10/13 REAR MOUNT PLATE
9	10-27467	10/13 MOTOR MOUNT
10	10-27468	10/13 HINGE ROD
11	10-27469	10/13 SHIELD SPACER
12	10-18245	UT10/13 LOWER SHIELD MOUNT
13	10-17487	UT13 PULLEY SHIELD EXTENSION -
14	10-17485	UT13 RIGHT PULLEY SHIELD
15	10-17486	UT13 LEFT PULLEY SHIELD
16	10-17396	PULLEY, 16 X 1.75, TRPL
17	10-18518	1-3/4 PILLOW BLOCK BEARING
17A	10-17527	1-3/4" BEARING ONLY
18	10-19935	B67 BELT
19	10-21095	1.753X 2.254 X 2 POROUS BRONZE BUSH
21	10-19222	GREASE FTG ZERK 1/4-28 SAE CZ PLTD
22	10-17488	UT13 SIDE HOPPER PANEL
23	10-17489	UT13 BACK HOPPER PANEL
24	10-17490	UT13 FRONT HOPPER PANEL
25	10-18541	SQAURE KEY, 3/8" X 3-3/8"
26	10-19271	COTTER PIN 1/8 X 1-1/2 C.ZINC PLTD
27	10-19274	SELF TAPPING SCREW 9900132
28	10-27249	WC1335 ADJUST BOLT
29	10-18545	BOLT 5/8" X 4-1/2" 9900172
30	10-18544	BOLT 5/8" X 1-3/4" PLTD
31	10-19589	BOLT 1/2" X 1-1/2" 9900536
32	10-18698	BOLT 7/16" X 1-1/4" 9900219
33	10-18955	BOLT 3/8" X 1" 9900699
34	10-19537	1/4X1/2 BOLT WSHR HEAD9900170
35	10-19864	NUT, 5/8"HEX
36	10-19600	LOCKNUT 5/8" 9900831
37	10-19599	LOCKNUT 1/2" 9900538
38	10-19598	LOCKNUT 7/16" 9900643
39	10-17402	LOCKNUT 3/8" 0601007
40	10-19594	WHIZNUT 1/4" 9900130
41	10-17401	WASHER 1/2" FLAT 9900565



514 W. Crawford Street
Clay Center, Kansas, 67432 USA
Phone: (800) 523-6993 or (785) 632-2161
Fax: (785) 632-5964
Website: www.hutchinson-mayrath.com
Email: sales@hutchinson-mayrath.com

©Ag Growth International Inc. 2020
Printed in Canada